


Congratulations on your purchase of the Supa-Trem™ by Fulltone!

- Bypass switch-** Turns pedal on and off...when unit is off, signal goes from input to output and won't ruin your sound or affect other pedals in chain.
- Speed switch-** doubles or halves the speed depending on what mode you're in....stays in tempo too!
- Hard /Soft switch-** goes from regular tremolo to hard on/off "toggle-switch" style stutter no matter where the "Mix" knob is set
- Rate knob-** controls speed of tremolo
- Mix knob-** pans between straight guitar sound and tremolo effect....towards the *left* is less effect/more guitar...to the *right* gets more effect, less guitar.

Internal Trimmers:



Trimmer #1: (see photo) Turning this trimmer CW (clockwise) *increases* the Volume of the pedal only when the pedal is turned ON.

Trimmer# 2 (see photo) adjusts the amount of "juice" (current) that gets to the photocell and ONLY affects the "soft mode." For a change in the feel of the tremolo, turn this Clockwise for a more intense/hard-edged rolling feel, or CCW for a softer more natural feel.

Tone Tip!!!! I've been getting calls from guys who are leaving it on the "Hard" setting with the "Mix" knob almost full-counter-clockwise for a normal trem sound, and when they switch to "Soft"...there is no effect except for a beautiful tone enhancement AND a healthy increase in volume depending on where you set the #1 Trimmer!
Try going to bypass and back and notice this phenomenon. Some folks are leaving their Supa-Trems on all night as a tone-booster!

Always disconnect the "in" jack when not in use so that you won't run down the battery, and I recommend using a Carbon-Zinc battery such as the Eveready Classic or Super Heavy-Duty. This pedal has an adapter jack that accepts a Negative Center Pin 9volt DC, use only a 2.1mm shaft diameter connector with it.

Fulltone products carry a 5 year warranty to the original owner with proof of purchase. The Warranty covers damage by our errors only, and not any mod or repair done by anyone other than Fulltone without prior written consent! Batteries are not covered. Customer pays shipping in advance, and all warranty work must be preceded by a phone call for scheduling and must be accompanied by an official Fulltone Return Authorization form (available via email or fax) Fulltone Musical Products Inc. is not responsible for injuries incurred while using our products nor any damage to other items related or non related to the use our products.

Fulltone Musical Products Inc.

4220 Glencoe Ave.
Marina del Rey, CA 90292
310.821.4500 fax 821.4511
sales@fulltone.com
www.fulltone.com

Copyright 2003 FMP Inc. All rights Reserved